

Table of Contents

Introduction	vii
About This Textbook	x
How to Use the <i>National Electrical Code</i>	xii
About the Author	xv
About the Graphic Illustrator	xvi
Mike Holt Enterprises Team.....	xvii

ARTICLE 90—INTRODUCTION TO THE NATIONAL ELECTRICAL CODE	1
Rule 1 —90.1 Purpose of the <i>NEC</i>	1
Rule 2 —90.2 Scope of the <i>NEC</i>	2
Rule 3 —90.3 <i>Code</i> Arrangement.....	5
Rule 4 —90.4 Enforcement.....	5
Rule 5 —90.5 Mandatory Requirements and Explanatory Material. ...	7
Rule 6 —90.7 Examination of Equipment for Product Safety	7

CHAPTER 1—GENERAL

ARTICLE 110—REQUIREMENTS FOR ELECTRICAL INSTALLATIONS	9
Rule 7 —110.2 Approval of Conductors and Equipment	9
Rule 8 —110.3 Examination, Identification, Installation, and Use of Equipment	9
Rule 9 —110.14 Conductor Termination and Splicing.....	10
Rule 10 —110.16 Arc-Flash Hazard Warning	15
Rule 11 —110.24 Available Fault Current.....	15
Rule 12 —110.26 Spaces About Electrical Equipment.....	16

CHAPTER 2—WIRING AND PROTECTION

ARTICLE 200—USE AND IDENTIFICATION OF GROUNDED CONDUCTORS	23
Rule 13 —200.6 Grounded Conductor Identification.....	24
ARTICLE 210—BRANCH CIRCUITS	27
Rule 14 —210.4 Multiwire Branch Circuits.....	28
Rule 15 —210.5 Identification for Branch Circuits.....	31
Rule 16 —210.8 GFCI Protection.....	32
Rule 17 —210.12 Arc-Fault Circuit-Interrupter Protection for Dwelling Units.....	38
Rule 18 —210.19 Conductor Sizing.	39
Rule 19 —210.20 Overcurrent Protection.....	41

ARTICLE 225—OUTSIDE BRANCH CIRCUITS AND FEEDERS	43
Rule 20 —225.32 Disconnect Location	43
Rule 21 —225.33 Maximum Number of Disconnects.	44
Rule 22 —225.34 Grouping of Disconnects.....	45
ARTICLE 230—SERVICES	47
Rule 23 —230.71 Number of Disconnects.	48
Rule 24 —230.72 Grouping of Disconnects.....	49
ARTICLE 240—OVERCURRENT PROTECTION	51
Rule 25 —240.4 Protection of Conductors	51
Rule 26 —240.21 Overcurrent Protection Location in Circuit.....	55
ARTICLE 250—GROUNDING AND BONDING	61
Rule 27 —250.2 Definitions.....	61
Rule 28 —250.4 General Requirements for Grounding and Bonding.....	63
Rule 29 —250.6 Objectionable Current.....	69
Rule 30 —250.24 Service Equipment—Grounding and Bonding.	73
Rule 31 —250.30 Separately Derived Systems—Grounding and Bonding.....	78
Rule 32 —250.32 Buildings or Structures Supplied by a Feeder or Branch Circuit.....	84
Rule 33 —250.34 Generators—Portable and Vehicle-Mounted.	86
Rule 34 —250.50 Grounding Electrode System.....	87
Rule 35 —250.52 Grounding Electrode Types.....	88
Rule 36 —250.53 Grounding Electrode Installation Requirements. ..	90
Rule 37 —250.64 Grounding Electrode Conductor Installation.....	95
Rule 38 —250.66 Sizing Grounding Electrode Conductor	98
Rule 39 —250.92 Bonding Equipment for Services.....	99
Rule 40 —250.94 Intersystem Bonding Termination.....	102
Rule 41 —250.97 Bonding Metal Parts Containing 277V and 480V Circuits.....	104
Rule 42 —250.102 Bonding Conductors and Jumpers.	104
Rule 43 —250.104 Bonding of Piping Systems and Exposed Structural Metal.....	107
Rule 44 —250.106 Lightning Protection System	110
Rule 45 —250.118 Types of Equipment Grounding Conductors.....	111
Rule 46 —250.122 Sizing Equipment Grounding Conductor.	114
Rule 47 —250.142 Use of Neutral Conductor for Equipment Grounding.....	117

Rule 48—250.146 Connecting Receptacle Grounding Terminal to Metal Enclosure 118

Rule 49—250.148 Continuity and Attachment of Equipment Grounding Conductors in Boxes 121

CHAPTER 3—WIRING AND METHODS

ARTICLE 300—WIRING METHODS 123

Rule 50—300.3 Conductors..... 123

Rule 51—300.4 Protection Against Physical Damage 126

Rule 52—300.5 Underground Installations..... 129

Rule 53—300.10 Electrical Continuity..... 133

Rule 54—300.11 Securing and Supporting..... 133

Rule 55—300.12 Mechanical Continuity 134

Rule 56—300.15 Boxes or Conduit Bodies..... 136

Rule 57—300.21 Spread of Fire or Products of Combustion..... 138

Rule 58—300.22 Wiring in Ducts Not for Air Handling, Fabricated Ducts for Environmental Air, and Other Spaces for Environmental Air (Plenums) 139

ARTICLE 310—CONDUCTORS FOR GENERAL WIRING 143

Rule 59—310.15 Conductor Ampacity..... 143

ARTICLE 312—CABINETS, CUTOUT BOXES, AND METER SOCKET ENCLOSURES 151

Rule 60—312.8 Enclosures With Splices, Taps, and Feed-Through Conductors 151

ARTICLE 314—OUTLET, DEVICE, PULL AND JUNCTION BOXES; CONDUIT BODIES; AND HANDHOLE ENCLOSURES..... 153

Rule 61—314.16 Number of 6 AWG and Smaller Conductors in Boxes and Conduit Bodies..... 153

Rule 62—314.23 Support of Boxes and Conduit Bodies 157

Rule 63—314.28 Boxes and Conduit Bodies for Conductors 4 AWG and Larger..... 160

Rule 64—314.29 Wiring to be Accessible..... 163

CHAPTER 4—EQUIPMENT FOR GENERAL USE

ARTICLE 404—SWITCHES 165

Rule 65—404.2 Switch Connections..... 165

Rule 66—404.9 Switch Faceplates..... 167

ARTICLE 406—RECEPTACLES, CORD CONNECTORS, AND ATTACHMENT PLUGS (CAPS)..... 169

Rule 67—406.4 General Installation Requirements..... 169

Rule 68—406.9 Receptacles in Damp or Wet Locations..... 171

ARTICLE 408—SWITCHBOARDS AND PANELBOARDS 175

Rule 69—408.4 Field Identification..... 175

ARTICLE 430—MOTORS, MOTOR CIRCUITS, AND CONTROLLERS 177

Rule 70—430.6 Table FLC versus Motor Nameplate Current Rating..... 177

Rule 71—430.22 Single Motor Conductor Size..... 178

Rule 72—430.52 Branch-Circuit Short-Circuit and Ground-Fault Protection..... 179

Rule 73—430.102 Disconnect Requirement..... 180

ARTICLE 450—TRANSFORMERS 183

Rule 74—450.3 Overcurrent Protection..... 183

Rule 75—450.14 Disconnecting Means 184

PRACTICE QUESTIONS..... 185