

Table of Contents

INTRODUCTIONxiv

HOW TO USE THE NATIONAL ELECTRICAL CODExvii

ARTICLE 90—INTRODUCTION TO THE NATIONAL ELECTRICAL CODE..... 1

90.1 Purpose of the *NEC*..... 1
 90.2 Scope of the *NEC* 2
 90.3 Code Arrangement 4
 90.4 Enforcement..... 5
 90.5 Mandatory Requirements and Explanatory Material..... 6
 90.6 Formal Interpretations..... 7
 90.7 Examination of Equipment for Product Safety 7
 90.9 Units of Measurement 7
 Article 90—Practice Questions..... 8

CHAPTER 1—GENERAL 9

ARTICLE 100—DEFINITIONS11
 Article 100. Definitions—Practice Questions34

ARTICLE 110—REQUIREMENTS FOR ELECTRICAL INSTALLATIONS37

Part I. General Requirements37

110.1 Scope.....37
 110.2 Approval of Conductors and Equipment37
 110.3 Examination, Identification, Installation, and Use of Equipment37
 110.4 Voltages.....38
 110.5 Copper Conductors.....38
 110.6 Conductor Sizes39
 110.7 Wiring Integrity.....39
 110.8 Suitable Wiring Methods40
 110.9 Interrupting Protection Rating.....40
 110.10 Short-Circuit Current Rating41
 110.11 Deteriorating Agents.....41
 110.12 Mechanical Execution of Work.....42
 110.13 Mounting and Cooling of Equipment.....43
 110.14 Conductor Termination and Splicing44
 110.15 High-Leg Conductor Identification.....48
 110.16 Flash Protection Warning48
 110.20 Enclosure Types49
 110.21 Manufacturer’s Markings.....49
 110.22 Identification of Disconnecting Means49

Part II. 600V, Nominal, or Less50

110.26 Spaces About Electrical Equipment50
 110.27 Guarding.....55
 Article 110—Practice Questions.....57

CHAPTER 2—WIRING AND PROTECTION59

ARTICLE 200—USE AND IDENTIFICATION OF GROUNDED CONDUCTORS61

200.1 Scope61
 200.2 General61
 200.6 Neutral Conductor Identification.....62
 200.7 Use of White or Gray Color63
 200.9 Terminal Identification.....64
 200.10 Identification of Terminals.....64
 200.11 Polarity64
 Article 200—Practice Questions.....65

ARTICLE 210—BRANCH CIRCUITS66

Part I. General Provisions67

210.1 Scope67
 210.2 Other Articles.....67
 210.3 Branch-Circuit Rating.....67
 210.4 Multiwire Branch Circuits.....67
 210.5 Identification for Branch Circuits.....69
 210.7 Branch-Circuit Requirements for Devices70
 210.8 GFCI Protection70
 210.11 Branch Circuits Required75
 210.12 Arc-Fault Circuit-Interrupter—Protected Circuits77
 210.18 Guest Rooms and Guest Suites79

Part II. Branch-Circuit Ratings79

210.19 Conductor Sizing79
 210.20 Overcurrent Protection.....80
 210.21 Outlet Device Rating.....81
 210.23 Permissible Loads82
 210.25 Branch Circuits in Buildings with Multiple Occupancies...83

Part III. Required Outlets83

210.50 General83
 210.52 Dwelling Unit Receptacle Outlet Requirements83
 210.60 Receptacles in Guest Rooms, Guest Suites, Dormitories, and Similar Occupancies91
 210.62 Show Windows.....91
 210.63 Heating, Air-Conditioning, and Refrigeration (HACR) Equipment92
 210.70 Lighting Outlet Requirements.....92
 Article 210—Practice Questions.....96

ARTICLE 215—FEEDERS99

215.1 Scope99
 215.2 Minimum Rating.....99
 215.3 Overcurrent Protection.....101
 215.6 Equipment Grounding Conductor101
 215.10 Ground-Fault Protection of Equipment.....101
 215.12 Identification for Feeders102
 Article 215—Practice Questions.....103

Table of Contents

ARTICLE 220—BRANCH-CIRCUIT, FEEDER, AND SERVICE CALCULATIONS

Part I. General	104
220.1 Scope	104
220.3 Application of Other Articles	104
220.5 Calculations	104
Part II. Branch-Circuit Load Calculations	105
220.12 General Lighting	105
220.14 Other Loads—All Occupancies	106
220.18 Maximum Load on a Branch Circuit	109
Part III. Feeder and Service Calculations	111
220.40 General	111
220.42 General Lighting Demand Factors	111
220.43 Commercial—Show Window and Track Lighting Load	111
220.44 Other than Dwelling Unit—Receptacle Load	112
220.50 Motor Load	112
220.51 Fixed Electric Space-Heating Load	113
220.52 Dwelling Unit—Small-Appliance and Laundry Load	113
220.53 Dwelling Unit—Appliance Load	113
220.54 Dwelling Unit—Electric Clothes Dryer Load	114
220.55 Dwelling Unit—Electric Ranges and Cooking Appliances	114
220.56 Commercial—Kitchen Equipment Load	116
220.60 Noncoincident Loads	117
220.61 Feeder/Service Neutral Unbalanced Load	117
Part IV. Optional Calculations for Computing Feeder and Service Loads	119
220.82 Dwelling Unit—Optional Load Calculation	119
220.84 Multifamily—Optional Load Calculation	121
220.85 Optional Calculation—Two Dwelling Units	122
220.87 Determining Existing Loads	122
Article 220—Practice Questions	123
ARTICLE 225—OUTSIDE BRANCH CIRCUITS AND FEEDERS	124
Part I. General Requirements	124
225.1 Scope	124
225.2 Other Articles	124
225.6 Minimum Size of Conductors	125
225.7 Luminaires Installed Outdoors	125
225.15 Supports Over Buildings	125
225.16 Attachment	125
225.17 Masts as Support	126
225.18 Clearance for Overhead Conductors	126
225.19 Clearances from Buildings	127
225.22 Raceways on Exterior Surfaces of Buildings or Other Structures	128
225.26 Trees for Conductor Support	128
Part II. More Than One Building or Structure	128
225.30 Number of Supplies	128
225.31 Disconnecting Means	129
225.32 Disconnect Location	129
225.33 Maximum Number of Disconnects	130
225.34 Grouping of Disconnects	130
225.35 Access to Occupants	130

225.36 Identified as Suitable for Service Equipment	130
225.37 Identification of Multiple Feeders	131
225.38 Disconnect Construction	131
225.39 Rating of Disconnecting Means	131
Article 225—Practice Questions	132

ARTICLE 230—SERVICES

Part I. General	134
230.1 Scope	134
230.2 Number of Services	134
230.3 Not to Pass Through a Building or Structure	135
230.6 Conductors Considered Outside a Building	135
230.7 Service Conductors Separate from Other Conductors	135
230.8 Raceway Seals	136
230.9 Clearance from Building Openings	136
230.10 Vegetation as Support	137
Part II. Overhead Service-Drop Conductors	137
230.23 Size and Rating	137
230.24 Vertical Clearance for Service-Drop Conductors	137
230.26 Point of Attachment	138
230.27 Means of Attachment	138
230.28 Service Masts Used as Supports	139
Part III. Underground Service-Lateral Conductors	139
230.31 Service-Lateral Conductor Size and Rating	139
230.32 Protection Against Damage	139
Part IV. Service-Entrance Conductors	139
230.40 Number of Service-Entrance Conductor Sets	139
230.42 Size and Rating	140
230.43 Wiring Methods	141
230.44 Cable Trays	141
230.46 Spliced Conductors	141
230.50 Protection Against Physical Damage	141
230.51 Service Cable Supports	142
230.54 Overhead Service Locations	142
230.56 High-Leg Identification	142
Part V. Service Equipment—General	143
230.66 Identified as Suitable for Service Equipment	143
Part VI. Service Equipment—Disconnecting Means	143
230.70 General	143
230.71 Number of Disconnects	144
230.72 Grouping of Disconnects	144
230.76 Manual or Power Operated	145
230.79 Rating of Disconnect	145
230.82 Equipment Connected to the Supply Side of the Service Disconnect	146
Part VII. Service Equipment Overcurrent Protection	147
230.90 Overload Protection Required	147
230.95 Ground-Fault Protection of Equipment	147
Article 230—Practice Questions	149
ARTICLE 240—OVERCURRENT PROTECTION	151
Part I. General	151
240.1 Scope	151
240.2 Definitions	152

240.3 Protection of Equipment..... 152
 240.4 Protection of Conductors 153
 240.5 Protection of Flexible Cords and Fixture Wires..... 156
 240.6 Standard Ampere Ratings 156
 240.10 Supplementary Overcurrent Protection 157
 240.13 Ground-Fault Protection of Equipment..... 157
 240.15 Ungrounded Conductors 157

Part II. Location..... 159

240.21 Overcurrent Protection Location in Circuit..... 159
 240.24 Location of Overcurrent Devices 162

Part III. Enclosures 164

240.32 Damp or Wet Locations..... 164
 240.33 Vertical Position..... 164

Part V. Plug Fuses, Fuseholders, and Adapters 164

240.51 Edison-Base Fuse..... 164
 240.53 Type S Fuses 165
 240.54 Type S Fuses, Adapters, and Fuseholders 165

Part VI. Cartridge Fuses and Fuseholders..... 165

240.60 General 165
 240.61 Classification..... 166

Part VII. Circuit Breakers 166

240.80 Method of Operation..... 166
 240.81 Indicating..... 166
 240.83 Markings..... 166
 240.85 Applications..... 167
 Article 240—Practice Questions..... 169

ARTICLE 250—GROUNDING AND BONDING..... 171

Part I. General 171

250.1 Scope 171
 250.2 Definitions 171
 250.4 General Requirements for Grounding and Bonding..... 173
 250.6 Objectionable Current..... 179
 250.8 Termination of Grounding and Bonding Conductors.. 183
 250.10 Protection of Fittings..... 183
 250.12 Clean Surfaces 183

Part II. System Grounding and Bonding..... 183

250.20 Systems Required to be Grounded 183
 250.24 Service Equipment—Grounding and Bonding 185
 250.28 Main Bonding Jumper and System Bonding Jumper .. 190
 250.30 Separately Derived Systems—Grounding and Bonding 192
 250.32 Buildings or Structures Supplied by a Feeder or Branch Circuit..... 196
 250.34 Generators—Portable and Vehicle-Mounted..... 198
 250.35 Permanently Installed Generators..... 199
 250.36 High-Impedance Grounded Systems..... 199

Part III. Grounding Electrode System and Grounding Electrode Conductor 200

250.50 Grounding Electrode System 200
 250.52 Grounding Electrode Types..... 200
 250.53 Grounding Electrode Installation Requirements 203
 250.54 Auxiliary Grounding Electrodes..... 205
 250.56 Contact Resistance of Ground Rod to the Earth 206

Measuring the Ground Resistance 206

250.58 Common Grounding Electrode..... 208
 250.60 Lightning Protection Electrode 208
 250.62 Grounding Electrode Conductor..... 209
 250.64 Grounding Electrode Conductor Installation..... 209
 250.66 Sizing Grounding Electrode Conductor 211
 250.68 Termination to the Grounding Electrode 212
 250.70 Grounding Electrode Conductor Termination Fittings 213

Part IV. Grounding Enclosure, Raceway, and Service Cable Connections..... 214

250.86 Other Enclosures..... 214

Part V. Bonding..... 214

250.92 Service Raceways and Enclosures..... 214
 250.94 Intersystem Bonding Terminal..... 216
 250.96 Bonding Other Enclosures 218
 250.97 Bonding Metal Parts Containing 277V and 480V Circuits 218
 250.102 Equipment Bonding Jumpers..... 220
 250.104 Bonding of Piping Systems and Exposed Structural Metal 221
 250.106 Lightning Protection System 224

Part VI. Equipment Grounding and Equipment Grounding Conductors..... 224

250.110 Fixed Equipment Connected by Permanent Wiring Methods—General..... 224
 250.112 Fastened in Place or Connected by Permanent Wiring Methods (Fixed)..... 224
 250.114 Cord-and-Plug-Connected Equipment..... 225
 250.118 Types of Equipment Grounding Conductors..... 225
 250.119 Identification of Equipment Grounding Conductors .. 228
 250.122 Sizing Equipment Grounding Conductor..... 230

Part VII. Methods of Equipment Grounding..... 232

250.130 Replacing Nongrounding Receptacles..... 232
 250.134 Equipment Fastened in Place or Connected by Wiring Methods..... 232
 250.136 Equipment Considered Grounded 233
 250.138 Cord-and-Plug-Connected Equipment..... 233
 250.140 Ranges, Ovens, and Clothes Dryers..... 233
 250.142 Use of Neutral Conductor for Equipment Grounding .. 234
 250.146 Connecting Receptacle Grounding Terminal to Metal Enclosure..... 235
 250.148 Continuity and Attachment of Equipment Grounding Conductors in Boxes 237
 Article 250—Practice Questions..... 239

ARTICLE 285—SURGE PROTECTIVE DEVICES (SPDs)..... 244

Part I. General 244

285.1 Scope 244
 285.3 Uses Not Permitted..... 244
 285.4 Number Required 244
 285.5 Listing..... 244
 285.6 Short-Circuit Current Rating 244

Part II. Installation 245

285.11 Location..... 245
 285.12 Routing of Conductors 245

Table of Contents

Part III. Connecting Surge Protective Devices	245
285.23 Type 1 SPD—Line Side of Service Equipment.....	245
285.24 Type 2 SPD—Feeder Circuits.....	245
285.25 Type 3 SPD—Branch Circuits.....	246
Article 285—Practice Questions.....	247

CHAPTER 3—WIRING METHODS AND MATERIALS..... 249

ARTICLE 300—WIRING METHODS..... 253

Part I. General Requirements	253
300.1 Scope.....	253
300.3 Conductors.....	254
300.4 Protection Against Physical Damage.....	255
300.5 Underground Installations.....	258
300.6 Protection Against Corrosion and Deterioration.....	262
300.7 Raceways Exposed to Different Temperatures.....	263
300.8 Not Permitted in Raceways.....	264
300.9 Raceways in Wet Locations Above Grade.....	264
300.10 Electrical Continuity.....	264
300.11 Securing and Supporting.....	265
300.12 Mechanical Continuity.....	266
300.13 Splices and Pigtails.....	267
300.14 Length of Free Conductors.....	268
300.15 Boxes or Conduit Bodies.....	269
300.17 Raceway Sizing.....	271
300.18 Inserting Conductors in Raceways.....	273
300.19 Supporting Conductors in Vertical Raceways.....	274
300.20 Induced Currents in Ferrous Metal Enclosures and Raceways.....	274
300.21 Spread of Fire or Products of Combustion.....	275
300.22 Ducts, Plenums, and Other Air-Handling Spaces.....	276
300.23 Panels Designed to Allow Access.....	278
Article 300—Practice Questions.....	279

ARTICLE 310—CONDUCTORS FOR GENERAL WIRING..... 282

310.1 Scope.....	282
310.2 Conductors.....	282
310.3 Stranded Conductors.....	282
310.4 Conductors in Parallel.....	283
310.5 Minimum Size Conductors.....	285
310.8 Location.....	285
310.9 Corrosive Conditions.....	285
310.10 Insulation Temperature Limitation.....	285
310.12 Conductor Identification.....	286
310.13 Conductor Construction.....	286
310.15 Conductor Ampacity.....	287
Article 310—Practice Questions.....	295

ARTICLE 312—CABINETS, CUTOUT BOXES, AND METER SOCKET ENCLOSURES..... 296

312.1 Scope.....	296
Part I. Installation	296
312.2 Damp or Wet Locations.....	296
312.3 Installed in Walls.....	297
312.4 Repairing Gaps.....	297

312.5 Enclosures.....	297
312.8 Used for Raceway and Splices.....	298
Article 312—Practice Questions.....	299

ARTICLE 314—OUTLET, DEVICE, PULL AND JUNCTION BOXES; CONDUIT BODIES; AND HANDHOLE ENCLOSURES..... 300

Part I. General	300
314.1 Scope.....	300
314.3 Nonmetallic Boxes.....	300
314.4 Metal Boxes.....	300
314.5 Short-Radius Conduit Bodies.....	300
Part II. Installation	301
314.15 Damp or Wet Locations.....	301
314.16 Number of 6 AWG and Smaller Conductors in Boxes and Conduit Bodies.....	301
314.17 Conductors That Enter Boxes or Conduit Bodies.....	305
314.20 Boxes Recessed in Walls or Ceilings.....	306
314.21 Repairing Gaps Around Boxes.....	307
314.22 Surface Extensions.....	307
314.23 Support of Boxes and Conduit Bodies.....	307
314.25 Covers and Canopies.....	309
314.27 Outlet Box.....	310
314.28 Boxes and Conduit Bodies for Conductors 4 AWG and Larger.....	310
314.29 Wiring to be Accessible.....	312
314.30 Handhole Enclosures.....	313
Article 314—Practice Questions.....	315

ARTICLE 320—ARMORED CABLE (TYPE AC)..... 317

Part I. General	317
320.1 Scope.....	317
320.2 Definition.....	317
Part II. Installation	317
320.10 Uses Permitted.....	317
320.12 Uses Not Permitted.....	318
320.15 Exposed Work.....	318
320.17 Through or Parallel to Framing Members.....	318
320.23 In Accessible Attics or Roof Spaces.....	318
320.24 Bends.....	319
320.30 Securing and Supporting.....	319
320.40 Boxes and Fittings.....	320
320.80 Conductor Ampacities.....	320
Part III. Construction Specifications	321
320.100 Construction.....	321
320.108 Equipment Grounding Conductor.....	321
Article 320—Practice Questions.....	322

ARTICLE 330—METAL-CLAD CABLE (TYPE MC)..... 323

Part I. General	323
330.1 Scope.....	323
330.2 Definition.....	323
Part II. Installation	323
330.10 Uses Permitted.....	323
330.12 Uses Not Permitted.....	324
330.17 Through or Parallel to Framing Members.....	324

330.23 In Accessible Attics or Roof Spaces 325
 330.24 Bends 325
 330.30 Securing and Supporting 325
 330.40 Fittings 326
 330.80 Conductor Ampacities 327
Part III. Construction Specifications 327
 330.108 Equipment Grounding Conductor 327
 Article 330—Practice Questions 328

ARTICLE 334—NONMETALLIC-SHEATHED CABLE (TYPES NM AND NMC) 329

Part I. General 329
 334.1 Scope 329
 334.2 Definition 329
 334.6 Listed 329
Part II. Installation 329
 334.10 Uses Permitted 329
 334.12 Uses Not Permitted 330
 334.15 Exposed 331
 334.17 Through or Parallel to Framing Members 331
 334.23 Attics and Roof Spaces 332
 334.24 Bends 333
 334.30 Securing and Supporting 333
 334.80 Conductor Ampacity 334
Part III. Construction Specifications 335
 334.100 Construction 335
 334.104 Conductors 335
 334.108 Equipment Grounding Conductor 335
 334.112 Insulation 335
 Article 334—Practice Questions 336

ARTICLE 338—SERVICE-ENTRANCE CABLE (TYPES SE AND USE) 337

Part I. General 337
 338.1 Scope 337
 338.2 Definitions 337
Part II. Installation 337
 338.10 Uses Permitted 337
 338.12 Uses Not Permitted 338
 338.24 Bends 338
 Article 338—Practice Questions 339

ARTICLE 340—UNDERGROUND FEEDER AND BRANCH-CIRCUIT CABLE (TYPE UF) 340

Part I. General 340
 340.1 Scope 340
 340.2 Definition 340
 340.6 Listing Requirements 340
Part II. Installation 340
 340.10 Uses Permitted 340
 340.12 Uses Not Permitted 340
 340.24 Bends 341
 340.80 Ampacity 341
 340.112 Insulation 341

Article 340—Practice Questions 342

ARTICLE 342—INTERMEDIATE METAL CONDUIT (TYPE IMC) 343

Part I. General 343
 342.1 Scope 343
 342.2 Definition 343
 342.6 Listing Requirements 343
Part II. Installation 343
 342.10 Uses Permitted 343
 342.14 Dissimilar Metals 344
 342.20 Trade Size 344
 342.22 Number of Conductors 344
 342.24 Bends 344
 342.26 Number of Bends (360°) 344
 342.28 Reaming 344
 342.30 Securing and Supporting 344
 342.42 Couplings and Connectors 346
 342.46 Bushings 346
 Article 342—Practice Questions 348

ARTICLE 344—RIGID METAL CONDUIT (TYPE RMC) 349

Part I. General 349
 344.1 Scope 349
 344.2 Definition 349
 344.6 Listing Requirements 349
Part II. Installation 349
 344.10 Uses Permitted 349
 344.14 Dissimilar Metals 350
 344.20 Trade Size 350
 344.22 Number of Conductors 350
 344.24 Bends 350
 344.26 Number of Bends (360°) 350
 344.28 Reaming 350
 344.30 Securing and Supporting 350
 344.42 Couplings and Connectors 352
 344.46 Bushings 352
 Article 344—Practice Questions 354

ARTICLE 348—FLEXIBLE METAL CONDUIT (TYPE FMC) 355

Part I. General 355
 348.1 Scope 355
 348.2 Definition 355
 348.6 Listing Requirements 355
Part II. Installation 355
 348.10 Uses Permitted 355
 348.12 Uses Not Permitted 355
 348.20 Trade Size 355
 348.22 Number of Conductors 356
 348.24 Bends 356
 348.26 Number of Bends (360°) 356
 348.28 Trimming 356
 348.30 Securing and Supporting 356
 348.42 Fittings 357
 348.60 Grounding and Bonding 357
 Article 348—Practice Questions 359

Table of Contents

ARTICLE 350—LIQUIDTIGHT FLEXIBLE METAL CONDUIT (TYPE LFMC)

Part I. General	360
350.1 Scope	360
350.2 Definition	360
350.6 Listing Requirements	360
Part II. Installation	360
350.10 Uses Permitted	360
350.12 Uses Not Permitted	360
350.20 Trade Size	360
350.22 Number of Conductors	361
350.24 Bends	361
350.26 Number of Bends (360°)	361
350.30 Securing and Supporting	361
350.42 Fittings	362
350.60 Grounding and Bonding	362
Article 350—Practice Questions	364

ARTICLE 352—RIGID POLYVINYL CHLORIDE CONDUIT (TYPE PVC)

Part I. General	365
352.1 Scope	365
352.2 Definition	365
Part II. Installation	365
352.10 Uses Permitted	365
352.12 Uses Not Permitted	366
352.20 Trade Size	367
352.22 Number of Conductors	367
352.24 Bends	367
352.26 Number of Bends (360°)	367
352.28 Trimming	367
352.30 Securing and Supporting	367
352.44 Expansion Fittings	368
352.46 Bushings	369
352.48 Joints	370
352.60 Equipment Grounding Conductor	370
Article 352—Practice Questions	371

ARTICLE 356—LIQUIDTIGHT FLEXIBLE NONMETALLIC CONDUIT (TYPE LFNC)

Part I. General	372
356.1 Scope	372
356.2 Definition	372
356.6 Listing Requirement	372
Part II. Installation	372
356.10 Uses Permitted	372
356.12 Uses Not Permitted	373
356.20 Trade Size	373
356.22 Number of Conductors	373
356.24 Bends	373
356.26 Number of Bends (360°)	373
356.30 Securing and Supporting	373
356.42 Fittings	374
356.60 Equipment Grounding Conductor	374
Article 356—Practice Questions	375

ARTICLE 358—ELECTRICAL METALLIC TUBING (TYPE EMT)

Part I. General	376
358.1 Scope	376
358.2 Definition	376
358.6 Listing Requirement	376
Part II. Installation	376
358.10 Uses Permitted	376
358.12 Uses Not Permitted	377
358.20 Trade Size	377
358.22 Number of Conductors	377
358.24 Bends	377
358.26 Number of Bends (360°)	378
358.28 Reaming and Threading	378
358.30 Securing and Supporting	378
358.42 Couplings and Connectors	379
Article 358—Practice Questions	380

ARTICLE 362—ELECTRICAL NONMETALLIC TUBING (TYPE ENT)

Part I. General	381
362.1 Scope	381
362.2 Definition	381
Part II. Installation	381
362.10 Uses Permitted	381
362.12 Uses Not Permitted	383
362.20 Trade Sizes	384
362.22 Number of Conductors	384
362.24 Bends	384
362.26 Number of Bends (360°)	384
362.28 Trimming	384
362.30 Securing and Supporting	384
362.46 Bushings	385
362.48 Joints	385
362.60 Equipment Grounding Conductor	385
Article 362—Practice Questions	386

ARTICLE 376—METAL WIREWAYS

Part I. General	387
376.1 Scope	387
376.2 Definition	387
Part II. Installation	387
376.10 Uses Permitted	387
376.12 Uses Not Permitted	387
376.21 Conductors—Maximum Size	387
376.22 Number of Conductors and Ampacity	387
376.23 Wireway Sizing	387
376.30 Supports	389
376.56 Splices, Taps, and Power Distribution Blocks	389
Article 376—Practice Questions	390

ARTICLE 380—MULTIOUTLET ASSEMBLIES

380.1 Scope	391
380.2 Uses	391
380.3 Through Partitions	391
Article 380—Practice Questions	392

ARTICLE 386—SURFACE METAL RACEWAYS 393

Part I. General 393
 386.1 Scope 393
 386.2 Definition 393
 386.6 Listing Requirements 393

Part II. Installation 393
 386.10 Uses Permitted 393
 386.12 Uses Not Permitted 394
 386.21 Size of Conductors 394
 386.22 Number of Conductors 394
 386.30 Securing and Supporting 394
 386.56 Splices and Taps 394
 386.60 Equipment Grounding Conductor 394
 386.70 Separate Compartments 395
 Article 386—Practice Questions 396

ARTICLE 392—CABLE TRAYS 397

Part I. General 397
 392.1 Scope 397
 392.2 Definition 397

Part II. Installation 397
 392.3 Uses Permitted 397
 392.4 Uses Not Permitted 398
 392.6 Installation 399
 392.7 Equipment Grounding Conductor 399
 392.8 Cable Installation 400
 392.9 Number of Multiconductor Cables in Cable Trays 400
 392.11 Conductor Ampacity of Multiconductor Cables in Cable Trays 400
 Article 392—Practice Questions 401

CHAPTER 4—EQUIPMENT FOR GENERAL USE 403

ARTICLE 400—FLEXIBLE CORDS AND FLEXIBLE CABLES 405

400.1 Scope 405
 400.3 Suitability 405
 400.4 Types of Flexible Cords and Flexible Cables 405
 400.5 Ampacity of Flexible Cords and Flexible Cables 405
 400.7 Uses Permitted 406
 400.8 Uses Not Permitted 407
 400.10 Pull at Joints and Terminals 408
 400.13 Overcurrent Protection 408
 400.14 Protection from Damage 409
 400.22 Neutral Conductor Identification 409
 400.23 Equipment Grounding Conductor Identification 409
 Article 400—Practice Questions 410

ARTICLE 402—FIXTURE WIRES 411

402.1 Scope 411
 402.3 Types 411
 402.5 Allowable Ampacity of Fixture Wires 411
 402.6 Minimum Size 411
 402.7 Raceway Size 411
 402.8 Neutral Conductor 412

402.10 Uses Permitted 412
 402.11 Uses Not Permitted 412
 402.12 Overcurrent Protection 412
 Article 402—Practice Questions 413

ARTICLE 404—SWITCHES 414

404.1 Scope 414
 404.2 Switch Connections 414
 404.3 Switch Enclosures 415
 404.4 Damp or Wet Locations 415
 404.6 Position of Knife Switches 416
 404.7 Indicating 416
 404.8 Accessibility and Grouping 416
 404.9 Switch Faceplates 418
 404.10 Mounting Snap Switches 419
 404.11 Circuit Breakers Used as Switches 419
 404.12 Grounding of Enclosures 419
 404.14 Rating and Use of Snap Switches 419
 404.15 Switch Marking 420
 Article 404—Practice Questions 421

ARTICLE 406—RECEPTACLES, CORD CONNECTORS, AND ATTACHMENT PLUGS (CAPS) 422

406.1 Scope 422
 406.2 Receptacle Rating and Type 422
 406.3 General Installation Requirements 423
 406.4 Receptacle Mounting 425
 406.5 Receptacle Faceplates 427
 406.6 Attachment Plugs, Cord Connectors, and Flanged Surface Devices 427
 406.8 Receptacles in Damp or Wet Locations 427
 406.10 Connecting Receptacle Grounding Terminal to Equipment Grounding Conductor 429
 406.11 Tamper-Resistant Receptacles in Dwelling Units 429
 Article 406—Practice Questions 430

ARTICLE 408—SWITCHBOARDS AND PANELBOARDS 431

Part I. General 431
 408.1 Scope 431
 408.3 Arrangement of Busbars and Conductors 431
 408.4 Circuit Directory or Circuit Identification 432
 408.5 Clearance for Conductors Entering Bus Enclosures 433
 408.7 Unused Openings 433
Part III. Panelboards 433
 408.36 Overcurrent Protection of Panelboards 433
 408.37 Panelboards in Damp or Wet Locations 434
 408.40 Equipment Grounding Conductor 434
 408.41 Neutral Conductor Terminations 436
 408.54 Maximum Number of Overcurrent Devices 436
 Article 408—Practice Questions 437

ARTICLE 410—LUMINAIRES, LAMP HOLDERS, AND LAMPS 438

Part I. General 438
 410.1 Scope 438
 410.2 Definitions 439
 410.6 Listing Required 439

Table of Contents

Part II. Luminaire Locations	439	422.18	Support of Ceiling Paddle Fans	461
410.10 Luminaires in Specific Locations.....	439	Part III. Disconnect		461
410.11 Luminaires Near Combustible Material.....	441	422.31 Permanently Connected Appliance Disconnects		461
410.16 Clothes Closets	441	422.33 Cord-and-Plug-Connected Appliance Disconnects		461
410.18 Space for Cove Lighting.....	442	422.34 Unit Switches as Disconnects.....		462
Part III. Luminaire Outlet Boxes and Covers	442	422.51 Cord-and-Plug-Connected Vending Machines.....		462
410.22 Outlet Boxes to be Covered.....	442	422.52 Electric Drinking Fountains.....		463
410.24 Connection of Electric-Discharge Luminaires	443	Article 422—Practice Questions.....		464
Part IV. Luminaire Supports	443	ARTICLE 424—FIXED ELECTRIC SPACE-HEATING EQUIPMENT		465
410.30 Supports.....	443	Part I. General		465
410.36 Means of Support.....	445	424.1 Scope		465
Part V. Grounding (Bonding)	445	424.3 Branch Circuits		465
410.42 Exposed Luminaire Parts	445	424.9 Permanently Installed Electric Baseboard Heaters with Receptacles.....		466
410.46 Methods of Grounding.....	446	Part III. Electric Space-Heating Equipment		466
Part VI. Wiring of Luminaires	446	424.19 Disconnecting Means.....		466
410.50 Polarization of Luminaires	446	Part V. Electric Space-Heating Cables		467
410.62 Cord-Connected Luminaires.....	446	424.44 Installation of Cables in Concrete or Poured Masonry Floors		467
410.64 Luminaires Used as a Raceway	447	Part VI. Duct Heaters		467
410.65 Luminaires Connected Together	447	424.65 Disconnect for Electric Duct Heater Controllers.....		467
410.68 Branch-Circuit Conductors and Ballasts.....	447	Article 424—Practice Questions.....		468
Part VIII. Lampholders	447	ARTICLE 430—MOTORS, MOTOR CIRCUITS, AND CONTROLLERS		469
410.90 Screw-Shell Lampholders.....	447	Part I. General		469
Part XI. Recessed Luminaires	448	430.1 Scope		469
410.115 Thermally Protected.....	448	430.2 Definitions		470
410.116 Recessed Luminaire Clearances	448	430.6 Table FLC Versus Motor Nameplate Current Rating... 471		
410.117 Wiring.....	448	430.8 Marking on Controllers		471
Part XIII. Electric-Discharge Lighting	449	430.9 Motor Controller Terminal Requirements		472
410.130 General	449	430.14 Location of Motors		472
410.136 Luminaire Mounting.....	449	430.17 The Highest Rated Motor		472
Part XV. Track Lighting	450	Part II. Conductor Size		472
410.151 Installation.....	450	430.22 Single Motor Conductor Size.....		472
410.154 Fastening.....	451	430.24 Several Motors—Conductor Size.....		473
Article 410—Practice Questions.....	452	430.28 Motor Feeder Taps.....		474
ARTICLE 411—LIGHTING SYSTEMS OPERATING AT 30V OR LESS	454	Part III. Overload Protection		474
411.1 Scope	454	430.31 Overload		474
411.2 Definition.....	454	430.32 Overload Sizing for Continuous-Duty Motors.....		474
411.3 Listing Required.....	454	430.36 Use of Fuses for Overload Protection		475
411.4 Specific Location Requirements	455	430.37 Number of Overload Devices.....		475
411.5 Secondary Circuits	455	Part IV. Branch-Circuit Short-Circuit and Ground-Fault Protection		475
Article 411—Practice Questions.....	456	430.51 General		475
ARTICLE 422—APPLIANCES	457	430.52 Branch-Circuit Short-Circuit and Ground-Fault Protection		476
Part I. General	457	430.55 Single Overcurrent Device.....		477
422.1 Scope	457	Part V. Feeder Short-Circuit and Ground-Fault Protection		477
422.3 Other Articles.....	457	430.62 Feeder Protection		477
Part II. Branch-Circuit Requirements	457	Part VI. Motor Control Circuits		478
422.10 Branch-Circuit Rating.....	457	430.72 Overcurrent Protection for Control Circuits.....		478
422.11 Overcurrent Protection.....	458			
422.12 Central Heating Equipment (Furnaces)	459			
422.13 Storage Water Heaters.....	459			
422.15 Central Vacuums.....	459			
422.16 Flexible Cords.....	460			

430.73 Protection of Conductors from Physical Damage479
 430.75 Disconnect for Control Circuits479
Part VII. Motor Controllers479
 430.83 Controller Rating.....479
 430.84 Need Not Open All Conductors of the Circuit479
 430.87 Controller for Each Motor.....479
Part IX. Disconnecting Means480
 430.102 Disconnect Requirement480
 430.103 Operation of Disconnect.....481
 430.104 Marking and Mounting481
 430.107 Readily Accessible.....481
 430.109 Disconnecting Means Rating481
 430.111 Combination Controller and Disconnect482
Part XIV. Tables.....482
 Article 430—Practice Questions.....483

ARTICLE 440—AIR-CONDITIONING AND REFRIGERATION EQUIPMENT.....485

Part I. General485
 440.1 Scope485
 440.2 Definitions485
 440.3 Other Articles.....485
 440.6 Ampacity and Rating485

Part II. Disconnecting Means.....486
 440.14 Location.....486
Part III. Overcurrent Protection487
 440.21 General487
 440.22 Short-Circuit and Ground-Fault Overcurrent Device Size.....487
Part IV. Conductor Sizing487
 440.32 Conductor Size for Single Motor-Compressors.....487
 440.33 Conductor Size for Several Motor-Compressors.....488
Part VII. Room Air Conditioners.....488
 440.62 Branch-Circuit Requirements.....488
 440.63 Disconnecting Means488
 440.64 Supply Cords489
 440.65 Leakage Current Detector-Interrupter and Arc-Fault Circuit Interrupter489
 Article 440—Practice Questions.....490

ARTICLE 450—TRANSFORMERS491

Part I. General491
 450.1 Scope491
 450.3 Overcurrent Protection.....491
 450.9 Ventilation.....492
 450.11 Marking492
 450.13 Transformer Accessibility.....492
 Article 450—Practice Questions.....494