

Table of Contents

Introduction	xv
About This Textbook	xvii
How to Use the <i>National Electrical Code</i>	xix
About the Author	xxii
About the Graphic Illustrator	xxiii
Mike Holt Enterprises Team	xxiv

ARTICLE 90—INTRODUCTION TO THE NATIONAL ELECTRICAL CODE	1
90.1 Purpose of the <i>NEC</i>	1
90.2 Scope of the <i>NEC</i>	2
90.3 <i>Code</i> Arrangement	4
90.4 Enforcement	5
90.5 Mandatory Requirements and Explanatory Material	6
90.6 Formal Interpretations	7
90.7 Examination of Equipment for Product Safety	7
90.9 Units of Measurement	7
Article 90. Introduction—Practice Questions	8

CHAPTER 1—GENERAL

ARTICLE 100—DEFINITIONS	13
Definitions	13

ARTICLE 110—REQUIREMENTS FOR ELECTRICAL INSTALLATIONS

Part I. General Requirements	41
110.1 Scope	41
110.2 Approval of Conductors and Equipment	41
110.3 Examination, Identification, Installation, and Use of Equipment	41
110.4 Voltages	42
110.5 Copper Conductors	42
110.6 Conductor Sizes	42
110.7 Wiring Integrity	43
110.8 Suitable Wiring Methods	43
110.9 Interrupting Protection Rating	43
110.10 Circuit Impedance, Short-Circuit Current Rating, and Other Characteristics	45
110.11 Deteriorating Agents	45
110.12 Mechanical Execution of Work	46
110.13 Mounting and Cooling of Equipment	46

110.14 Conductor Termination and Splicing	46
110.15 High-Leg Conductor Identification	51
110.16 Arc-Flash Hazard Warning	52
110.21 Manufacturer's Markings	52
110.22 Identification of Disconnecting Means	52
110.24 Available Fault Current	52
Part II. 600V, Nominal, or Less	53
110.26 Spaces About Electrical Equipment	53
110.27 Guarding	59
110.28 Enclosure Types	59
Chapter 1. General—Practice Questions	60

CHAPTER 2—WIRING AND PROTECTION

ARTICLE 200—USE AND IDENTIFICATION OF GROUNDED CONDUCTORS

Part I. General	68
200.1 Scope	68
200.2 General	68
200.4 Grounded Conductors	68
200.6 Grounded Conductor Identification	68
200.7 Use of White or Gray Color	70
200.9 Terminal Identification	71
200.10 Identification of Terminals	71
200.11 Polarity	71

ARTICLE 210—BRANCH CIRCUITS

Part I. General Provisions	74
210.1 Scope	74
210.2 Other Articles	74
210.3 Branch-Circuit Rating	74
210.4 Multiwire Branch Circuits	74
210.5 Identification for Branch Circuits	78
210.6 Branch-Circuit Voltage Limitations	78
210.7 Multiple Branch Circuits	79
210.8 GFCI Protection	79
210.11 Branch Circuits Required	85
210.12 Arc-Fault Circuit-Interrupter Protection for Dwelling Units	87
210.18 Guest Rooms and Guest Suites	88
Part II. Branch-Circuit Ratings	88
210.19 Conductor Sizing	88
210.20 Overcurrent Protection	90

210.21 Outlet Device Rating	91	220.83 Existing Dwelling Unit Calculations.....	128
210.23 Permissible Loads.....	92	220.84 Multifamily—Optional Load Calculation	129
210.25 Branch Circuits in Buildings with Multiple Occupancies.....	93	220.85 Optional Calculation—Two Dwelling Units.....	130
Part III. Required Outlets.....	93	220.87 Determining Existing Loads.....	130
210.50 General.....	93	ARTICLE 225—OUTSIDE BRANCH CIRCUITS AND FEEDERS	131
210.52 Dwelling Unit Receptacle Outlet Requirements.....	93	Part I. General.....	131
210.60 Receptacles in Guest Rooms, Guest Suites, Dormitories, and Similar Occupancies	101	225.1 Scope	131
210.62 Show Windows	101	225.2 Other Articles	132
210.63 Heating, Air-Conditioning, and Refrigeration (HACR) Equipment	102	225.6 Minimum Size of Conductors	132
210.70 Lighting Outlet Requirements.....	103	225.7 Luminaires Installed Outdoors.....	133
ARTICLE 215—FEEDERS.....	107	225.15 Supports Over Buildings.....	133
215.1 Scope	107	225.16 Attachment.....	133
215.2 Minimum Rating	107	225.17 Masts as Support.....	133
215.3 Overcurrent Protection Sizing.....	109	225.18 Clearance for Overhead Conductors.....	133
215.4 Feeders with Common Neutral Conductor	109	225.19 Clearances from Buildings	134
215.6 Equipment Grounding Conductor.....	109	225.22 Raceways on Exterior Surfaces of Buildings or Other Structures.....	135
215.10 Ground-Fault Protection of Equipment.....	110	225.26 Trees for Conductor Support.....	136
215.12 Conductor Identification.....	110	225.27 Raceway Seal.....	136
ARTICLE 220—BRANCH-CIRCUIT, FEEDER, AND SERVICE CALCULATIONS.....	111	Part II. Buildings or Other Structures Supplied by a Feeder(s) or Branch Circuit(s).....	136
Part I. General.....	111	225.30 Number of Supplies	136
220.1 Scope	111	225.31 Disconnecting Means.....	136
220.3 Application of Other Articles	111	225.32 Disconnect Location	136
220.5 Calculations.....	111	225.33 Maximum Number of Disconnects	138
Part II. Branch-Circuit Load Calculations.....	112	225.34 Grouping of Disconnects.....	138
220.12 General Lighting	112	225.35 Access to Occupants.....	138
220.14 Other Loads—All Occupancies	113	225.36 Identified as Suitable for Service Equipment	138
220.18 Maximum Load on a Branch Circuit	116	225.37 Identification of Multiple Feeders	138
Part III. Feeder and Service Calculations.....	118	225.38 Disconnect Construction	138
220.40 General.....	118	225.39 Rating of Disconnecting Means.....	138
220.42 General Lighting Demand Factors	118	ARTICLE 230—SERVICES	140
220.43 Commercial—Show Window and Track Lighting Load	118	Part I. General.....	141
220.44 Other than Dwelling Unit—Receptacle Load.....	119	230.1 Scope	141
220.50 Motor Load	120	230.2 Number of Services	141
220.51 Fixed Electric Space-Heating Load.....	120	230.3 Not to Pass Through a Building/Structure	142
220.52 Dwelling Unit—Small-Appliance and Laundry Load	120	230.6 Conductors Considered Outside a Building.....	142
220.53 Dwelling Unit—Appliance Load.....	120	230.7 Service Conductors Separate from Other Conductors.....	142
220.54 Dwelling Unit—Electric Clothes Dryer Load	121	230.8 Raceway Seals	143
220.55 Dwelling Unit—Electric Ranges and Cooking Appliances... ..	122	230.9 Clearance from Building Openings	143
220.56 Commercial—Kitchen Equipment Load.....	124	230.10 Vegetation as Support.....	144
220.60 Noncoincident Loads	124	Part II. Overhead Service Conductors.....	144
220.61 Feeder/Service Neutral Unbalanced Load.....	124	230.23 Overhead Service Conductor Size and Rating.....	144
Part IV. Optional Calculations for Computing Feeder and Service Loads	127	230.24 Vertical Clearance for Overhead Service Conductors	145
220.82 Dwelling Unit—Optional Load Calculation.....	127	230.26 Point of Attachment	146
		230.27 Means of Attachment.....	146
		230.28 Service Masts Used as Supports.....	146

Part III. Underground Service Conductors	147	240.54 Type S Fuses, Adapters, and Fuseholders	173
230.31 Underground Service Conductor Size and Rating	147	Part VI. Cartridge Fuses and Fuseholders	174
230.32 Protection Against Damage	147	240.60 General	174
Part IV. Service-Entrance Conductors	148	240.61 Classification	174
230.40 Number of Service-Entrance Conductor Sets	148	Part VII. Circuit Breakers	175
230.42 Size and Rating	148	240.80 Method of Operation	175
230.43 Wiring Methods	149	240.81 Indicating	175
230.46 Spliced Conductors	149	240.82 Nontamperable	175
230.50 Protection Against Physical Damage	149	240.83 Markings	175
230.51 Cable Supports	150	240.85 Applications	176
230.54 Overhead Service Locations	150		
230.56 High-Leg Identification	150	ARTICLE 250—GROUNDING AND BONDING	177
Part V. Service Equipment—General	151	Part I. General	177
230.66 Listed as Suitable for Service Equipment	151	250.1 Scope	177
Part VI. Service Equipment—Disconnecting Means	151	250.2 Definitions	177
230.70 Disconnect Requirements	151	250.4 General Requirements for Grounding and Bonding	179
230.71 Number of Disconnects	153	250.6 Objectionable Current	185
230.72 Grouping of Disconnects	153	250.8 Termination of Grounding and Bonding Conductors	189
230.76 Manual or Power Operated	154	250.10 Protection of Fittings	189
230.77 Indicating	154	250.12 Clean Surfaces	189
230.79 Rating of Disconnect	154	Part II. System Grounding and Bonding	189
230.81 Connection to Terminals	155	250.20 Systems Required to be Grounded	189
230.82 Connected on Supply Side of the Service Disconnect	155	250.21 Ungrounded Systems—50V to Less Than 100V	190
Part VII. Service Equipment Overcurrent Protection	156	250.24 Service Equipment—Grounding and	
230.90 Overload Protection Required	156	Bonding	190
230.95 Ground-Fault Protection of Equipment	156	250.28 Main Bonding Jumper and System Bonding Jumper	195
ARTICLE 240—OVERCURRENT PROTECTION	158	250.30 Separately Derived Systems—Grounding and Bonding	197
Part I. General	158	250.32 Buildings or Structures Supplied by a Feeder or Branch	
240.1 Scope	158	Circuit	203
240.2 Definitions	159	250.34 Generators—Portable and Vehicle-Mounted	205
240.3 Protection of Equipment	160	250.35 Permanently Installed Generators	206
240.4 Protection of Conductors	160	250.36 High-Impedance Grounded Systems	206
240.5 Protection of Flexible Cords and Fixture Wires	163	Part III. Grounding Electrode System and Grounding Electrode	
240.6 Standard Ampere Ratings	164	Conductor	207
240.10 Supplementary Overcurrent Protection	164	250.50 Grounding Electrode System	207
240.13 Ground-Fault Protection of Equipment	164	250.52 Grounding Electrode Types	208
240.15 Ungrounded Conductors	165	250.53 Grounding Electrode Installation Requirements	210
Part II. Location	166	250.54 Auxiliary Grounding Electrodes	215
240.21 Overcurrent Protection Location in Circuit	166	250.58 Common Grounding Electrode	216
240.24 Location of Overcurrent Devices	170	250.60 Lightning Protection Electrode	217
Part III. Enclosures	172	250.62 Grounding Electrode Conductor	217
240.32 Damp or Wet Locations	172	250.64 Grounding Electrode Conductor Installation	218
240.33 Vertical Position	172	250.66 Sizing Grounding Electrode Conductor	220
Part V. Plug Fuses, Fuseholders, and Adapters	173	250.68 Termination to the Grounding Electrode	222
240.50 General	173	250.70 Grounding Electrode Conductor Termination Fittings	223
240.51 Edison-Base Fuses	173	Part IV. Grounding Enclosure, Raceway, and Service	
240.52 Edison-Base Fuseholders	173	Cable Connections	223
240.53 Type S Fuses	173	250.80 Service Raceways and Enclosures	223
		250.86 Other Enclosures	223

Part V. Bonding 224
 250.90 General..... 224
 250.92 Bonding Equipment for Services 224
 250.94 Intersystem Bonding Termination 227
 250.96 Bonding Other Enclosures 229
 250.97 Bonding Metal Parts Containing 277V and 480V Circuits ... 229
 250.102 Bonding Conductors and Jumpers 230
 250.104 Bonding of Piping Systems and Exposed Structural Metal 232
 250.106 Lightning Protection System 235
Part VI. Equipment Grounding and Equipment Grounding Conductors 236
 250.110 Fixed Equipment Connected by Permanent Wiring Methods—General 236
 250.112 Specific Equipment Fastened in Place or Connected by Permanent Wiring Methods 236
 250.114 Cord-and-Plug-Connected Equipment..... 237
 250.118 Types of Equipment Grounding Conductors 237
 250.119 Identification of Equipment Grounding Conductors 240
 250.120 Equipment Grounding Conductor Installation..... 242
 250.121 Use of Equipment Grounding Conductors 242
 250.122 Sizing Equipment Grounding Conductor 242
 250.126 Identification of Wiring Device Terminals 245
Part VII. Methods of Equipment Grounding 245
 250.130 Replacing Nongrounding Receptacles 245
 250.134 Equipment Fastened in Place or Connected by Wiring Methods 246
 250.136 Equipment Considered Grounded 247
 250.138 Cord-and-Plug-Connected Equipment..... 247
 250.140 Ranges, Ovens, and Clothes Dryers..... 247
 250.142 Use of Neutral Conductor for Equipment Grounding..... 247
 250.146 Connecting Receptacle Grounding Terminal to Metal Enclosure..... 248
 250.148 Continuity and Attachment of Equipment Grounding Conductors in Boxes 251
Part VIII. Direct-Current Systems 252
 250.166 Sizing Grounding Electrode Conductor 252
ARTICLE 285—SURGE PROTECTIVE DEVICES (SPDS) 254
Part I. General 255
 285.1 Scope 255
 285.3 Uses Not Permitted 255
 285.4 Number Required..... 255
 285.5 Listing 255
 285.6 Short-Circuit Current Rating..... 255
Part II. Installation..... 256
 285.11 Location 256
 285.12 Routing of Conductors 256

Part III. Connecting Surge protective devices..... 256
 285.23 Type 1 SPD—Line Side of Service Equipment..... 256
 285.24 Type 2 SPD—Feeder Circuits..... 256
 285.25 Type 3 SPDs—Branch Circuits..... 257
Chapter 2. Wiring and Protection—Practice Questions..... 258

CHAPTER 3—WIRING METHODS AND MATERIALS 273

ARTICLE 300—WIRING METHODS 277

Part I. General..... 277
 300.1 Scope 277
 300.3 Conductors 278
 300.4 Protection Against Physical Damage 280
 300.5 Underground Installations 283
 300.6 Protection Against Corrosion and Deterioration..... 287
 300.7 Raceways Exposed to Different Temperatures 288
 300.8 Not Permitted in Raceways 289
 300.9 Raceways in Wet Locations Above Grade 289
 300.10 Electrical Continuity 289
 300.11 Securing and Supporting..... 290
 300.12 Mechanical Continuity..... 292
 300.13 Splices and Pigtails..... 293
 300.14 Length of Free Conductors 294
 300.15 Boxes or Conduit Bodies 295
 300.16 Raceway or Cable to Open or Concealed Wiring 297
 300.17 Raceway Sizing 297
 300.18 Inserting Conductors in Raceways 299
 300.19 Supporting Conductors in Vertical Raceways..... 299
 300.20 Induced Currents in Ferrous Metal Enclosures and Raceways 300
 300.21 Spread of Fire or Products of Combustion 301
 300.22 Wiring in Ducts Not for Air Handling, Fabricated Ducts for Environmental Air, and Other Spaces For Environmental Air (Plenums) 302
 300.23 Panels Designed to Allow Access 304

ARTICLE 310—CONDUCTORS FOR GENERAL WIRING 306

Part I. General..... 306
 310.1 Scope 306
Part II. Installation..... 306
 310.10 Uses Permitted 306
 310.15 Conductor Ampacity..... 309
Part III. Construction Specification 316
 310.104 Conductor Construction and Application..... 316
 310.106 Conductors 318
 310.110 Conductor Identification 319

ARTICLE 312—CABINETS, CUTOUT BOXES, AND METER SOCKET ENCLOSURES

312.1 Scope	320
Part I. Installation	321
312.2 Damp or Wet Locations	321
312.3 Installed in Walls	321
312.4 Repairing Gaps	321
312.5 Enclosures	321
312.6 Deflection of Conductors	322
312.8 Enclosures With Splices, Taps, and Feed-Through Conductors	322

ARTICLE 314—OUTLET, DEVICE, PULL AND JUNCTION BOXES; CONDUIT BODIES; AND HANDHOLE ENCLOSURES

Part I. Scope and General	324
314.1 Scope	324
314.3 Nonmetallic Boxes	324
314.4 Metal Boxes	324
Part II. Installation	324
314.15 Damp or Wet Locations	324
314.16 Number of 6 AWG and Smaller Conductors in Boxes and Conduit Bodies	325
314.17 Conductors That Enter Boxes or Conduit Bodies	329
314.20 Boxes Recessed in Walls or Ceilings	330
314.21 Repairing Noncombustible Surfaces	330
314.22 Surface Extensions	330
314.23 Support of Boxes and Conduit Bodies	331
314.27 Outlet Box	334
314.28 Boxes and Conduit Bodies for Conductors 4 AWG and Larger	335
314.29 Wiring to be Accessible	339
314.30 Handhole Enclosures	339

ARTICLE 320—ARMORED CABLE (TYPE AC)

Part I. General	341
320.1 Scope	341
320.2 Definition	341
Part II. Installation	341
320.10 Uses Permitted	341
320.12 Uses Not Permitted	342
320.15 Exposed Work	342
320.17 Through or Parallel to Framing Members	342
320.23 In Accessible Attics or Roof Spaces	343
320.24 Bends	343
320.30 Securing and Supporting	343
320.40 Boxes and Fittings	344
320.80 Conductor Ampacity	345
Part III. Construction Specifications	345
320.100 Construction	345

320.108 Equipment Grounding Conductor	345
---------------------------------------	-----

ARTICLE 330—METAL-CLAD CABLE (TYPE MC)

Part I. General	346
330.1 Scope	346
330.2 Definition	346
Part II. Installation	346
330.10 Uses Permitted	346
330.12 Uses Not Permitted	347
330.17 Through or Parallel to Framing Members	347
330.23 In Accessible Attics or Roof Spaces	348
330.24 Bends	348
330.30 Securing and Supporting	348
330.40 Fittings	349
330.80 Conductor Ampacities	350
Part III. Construction Specifications	350
330.108 Equipment Grounding Conductor	350

ARTICLE 334—NONMETALLIC-SHEATHED CABLE (TYPES NM AND NMC)

Part I. General	351
334.1 Scope	351
334.2 Definition	351
334.6 Listed	351
Part II. Installation	352
334.10 Uses Permitted	352
334.12 Uses Not Permitted	353
334.15 Exposed	353
334.17 Through or Parallel to Framing Members	354
334.23 Attics and Roof Spaces	354
334.24 Bends	355
334.30 Securing and Supporting	355
334.80 Conductor Ampacity	356
Part III. Construction Specifications	358
334.100 Construction	358
334.104 Conductors	358
334.108 Equipment Grounding Conductor	358
334.112 Insulation	358

ARTICLE 338—SERVICE-ENTRANCE CABLE (TYPES SE AND USE)

Part I. General	359
338.1 Scope	359
338.2 Definitions	359
Part II. Installation	359
338.10 Uses Permitted	359
338.12 Uses Not Permitted	360
338.24 Bends	360

ARTICLE 340—UNDERGROUND FEEDER AND BRANCH-CIRCUIT CABLE (TYPE UF)	361
Part I. General	361
340.1 Scope	361
340.2 Definition	361
340.6 Listing Requirements	361
Part II. Installation	361
340.10 Uses Permitted	361
340.12 Uses Not Permitted	362
340.24 Bends	362
340.80 Ampacity	362
340.112 Insulation	362
ARTICLE 342—INTERMEDIATE METAL CONDUIT (TYPE IMC)	363
Part I. General	363
342.1 Scope	363
342.2 Definition	363
342.6 Listing Requirements	363
Part II. Installation	363
342.10 Uses Permitted	363
342.14 Dissimilar Metals	364
342.20 Trade Size	364
342.22 Number of Conductors	364
342.24 Bends	364
342.26 Number of Bends (360°)	364
342.28 Reaming	364
342.30 Securing and Supporting	365
342.42 Couplings and Connectors	366
342.46 Bushings	367
ARTICLE 344—RIGID METAL CONDUIT (TYPE RMC)	368
Part I. General	368
344.1 Scope	368
344.2 Definition	368
344.6 Listing Requirements	368
Part II. Installation	368
344.10 Uses Permitted	368
344.14 Dissimilar Metals	369
344.20 Trade Size	369
344.22 Number of Conductors	369
344.24 Bends	369
344.26 Number of Bends (360°)	369
344.28 Reaming	370
344.30 Securing and Supporting	370
344.42 Couplings and Connectors	371
344.46 Bushings	372
Part III. Construction Specifications	372
344.130 Standard Lengths	372
ARTICLE 348—FLEXIBLE METAL CONDUIT (TYPE FMC)	373
Part I. General	373
348.1 Scope	373
348.2 Definition	373
348.6 Listing Requirements	373
Part II. Installation	373
348.10 Uses Permitted	373
348.12 Uses Not Permitted	373
348.20 Trade Size	373
348.22 Number of Conductors	374
348.24 Bends	374
348.26 Number of Bends (360°)	374
348.28 Trimming	374
348.30 Securing and Supporting	374
348.42 Fittings	375
348.60 Grounding and Bonding	375
ARTICLE 350—LIQUIDTIGHT FLEXIBLE METAL CONDUIT (TYPE LFMC)	377
Part I. General	377
350.1 Scope	377
350.2 Definition	377
350.6 Listing Requirements	377
Part II. Installation	377
350.10 Uses Permitted	377
350.12 Uses Not Permitted	377
350.20 Trade Size	377
350.22 Number of Conductors	378
350.24 Bends	378
350.26 Number of Bends (360°)	378
350.30 Securing and Supporting	378
350.42 Fittings	379
350.60 Grounding and Bonding	379
ARTICLE 352—RIGID POLYVINYL CHLORIDE CONDUIT (TYPE PVC)	380
Part I. General	380
352.1 Scope	380
352.2 Definition	380
Part II. Installation	380
352.10 Uses Permitted	380
352.12 Uses Not Permitted	381
352.20 Trade Size	382
352.22 Number of Conductors	382
352.24 Bends	382
352.26 Number of Bends (360°)	382
352.28 Trimming	382
352.30 Securing and Supporting	382
352.44 Expansion Fittings	383

352.46 Bushings	384
352.48 Joints	384
352.60 Equipment Grounding Conductor.....	384

ARTICLE 356—LIQUIDTIGHT FLEXIBLE NONMETALLIC CONDUIT (TYPE LFNC)..... 386

Part I. General	386
356.1 Scope	386
356.2 Definition	386
356.6 Listing Requirement.....	386
Part II. Installation	386
356.10 Uses Permitted	386
356.12 Uses Not Permitted	387
356.20 Trade Size.....	387
356.22 Number of Conductors.....	387
356.24 Bends.....	387
356.26 Number of Bends (360°).....	387
356.30 Securing and Supporting.....	387
356.42 Fittings	388
356.60 Equipment Grounding Conductor.....	388

ARTICLE 358—ELECTRICAL METALLIC TUBING (TYPE EMT)..... 389

Part I. General	389
358.1 Scope	389
358.2 Definition	389
358.6 Listing Requirement.....	389
Part II. Installation	389
358.10 Uses Permitted	389
358.12 Uses Not Permitted	390
358.20 Trade Size.....	390
358.22 Number of Conductors.....	390
358.24 Bends.....	390
358.26 Number of Bends (360°).....	391
358.28 Reaming and Threading.....	391
358.30 Securing and Supporting.....	391
358.42 Couplings and Connectors	392

ARTICLE 362—ELECTRICAL NONMETALLIC TUBING (TYPE ENT)..... 393

Part I. General	393
362.1 Scope	393
362.2 Definition	393
Part II. Installation	393
362.10 Uses Permitted	393
362.12 Uses Not Permitted	395
362.20 Trade Sizes	396
362.22 Number of Conductors.....	396
362.24 Bends.....	396
362.26 Number of Bends (360°).....	396

362.28 Trimming	396
362.30 Securing and Supporting.....	396
362.46 Bushings	397
362.48 Joints	397
362.60 Equipment Grounding Conductor.....	397

ARTICLE 376—METAL WIREWAYS..... 398

Part I. General	398
376.1 Scope	398
376.2 Definition	398
Part II. Installation	398
376.10 Uses Permitted	398
376.12 Uses Not Permitted	398
376.21 Conductors—Maximum Size	398
376.22 Number of Conductors and Ampacity	398
376.23 Wireway Sizing	399
376.30 Supports.....	399
376.56 Splices, Taps, and Power Distribution Blocks.....	399

ARTICLE 380—MULTIOUTLET ASSEMBLIES..... 401

Part I. General	401
380.1 Scope	401
Part II. Installation	401
380.10 Uses Permitted	401
380.12 Uses Not Permitted	401
380.76 Through Partitions.....	401

ARTICLE 386—SURFACE METAL RACEWAYS..... 402

Part I. General	402
386.1 Scope	402
386.2 Definition	402
386.6 Listing Requirements.....	402
Part II. Installation	402
386.10 Uses Permitted	402
386.12 Uses Not Permitted	403
386.21 Size of Conductors.....	403
386.22 Number of Conductors.....	403
386.30 Securing and Supporting.....	403
386.56 Splices and Taps.....	403
386.60 Equipment Grounding Conductor.....	403
386.70 Separate Compartments	404

ARTICLE 392—CABLE TRAYS..... 405

Part I. General	405
392.1 Scope	405
392.2 Definition	405
Part II. Installation	405
392.10 Uses Permitted	405
392.12 Uses Not Permitted	406
392.18 Cable Tray Installations	406

392.20 Cable and Conductor Installation..... 407
 392.22 Number of Conductors or Cables 407
 392.30 Securing and Supporting..... 407
 392.46 Bushed Raceway 407
 392.56 Cable Splices..... 407
 392.60 Equipment Grounding Conductor..... 408
 392.80 Ampacity of Conductors 409
**Chapter 3. Wiring Methods And Materials—
 Practice Questions**..... 410

**CHAPTER 4—EQUIPMENT FOR
 GENERAL USE**..... 423

**ARTICLE 400—FLEXIBLE CORDS AND FLEXIBLE
 CABLES** 425
 400.1 Scope 425
 400.3 Suitability 425
 400.4 Types of Flexible Cords and Flexible Cables..... 425
 400.5 Ampacity of Flexible Cords and Flexible Cables 425
 400.7 Uses Permitted 426
 400.8 Uses Not Permitted 427
 400.10 Pull at Joints and Terminals 428
 400.14 Protection from Damage 429
 400.23 Equipment Grounding Conductor Identification..... 429

ARTICLE 402—FIXTURE WIRES 430
 402.1 Scope 430
 402.3 Types..... 430
 402.5 Allowable Ampacity of Fixture Wires..... 430
 402.6 Minimum Size..... 430
 402.7 Raceway Size 430
 402.8 Neutral Conductor..... 431
 402.10 Uses Permitted 431
 402.11 Uses Not Permitted 431
 402.12 Overcurrent Protection..... 431

ARTICLE 404—SWITCHES 432
 404.1 Scope 432
 404.2 Switch Connections 432
 404.3 Switch Enclosures 434
 404.4 Damp or Wet Locations..... 434
 404.6 Position of Knife Switches..... 435
 404.7 Indicating..... 435
 404.8 Accessibility and Grouping 436
 404.9 Switch Faceplates..... 436
 404.10 Mounting Snap Switches 438
 404.11 Circuit Breakers Used as Switches..... 438
 404.12 Grounding of Enclosures 438
 404.14 Rating and Use of Snap Switches..... 438
 404.15 Switch Marking..... 439

**ARTICLE 406—RECEPTACLES, CORD CONNECTORS,
 AND ATTACHMENT PLUGS (CAPS)**..... 440
 406.1 Scope 440
 406.2 Definitions 440
 406.3 Receptacle Rating and Type 440
 406.4 General Installation Requirements..... 441
 406.5 Receptacle Mounting 443
 406.6 Receptacle Faceplates 444
 406.7 Attachment Plugs, Cord Connectors, and Flanged Surface
 Devices..... 445
 406.9 Receptacles in Damp or Wet Locations..... 445
 406.11 Connecting Receptacle Grounding Terminal to
 Equipment Grounding Conductor..... 447
 406.12 Tamper-Resistant Receptacles in Dwelling Units 447
 406.13 Tamper-Resistant Receptacles in Guest Rooms and
 Guest Suites 447
 406.14 Tamper-Resistant Receptacles in Child Care Facilities 447

ARTICLE 408—SWITCHBOARDS AND PANELBOARDS 448
Part I. General..... 448
 408.1 Scope 448
 408.3 Arrangement of Busbars and Conductors 448
 408.4 Field Identification 450
 408.5 Clearance for Conductors Entering Bus Enclosures 450
 408.7 Unused Openings..... 450
Part III. Panelboards 451
 408.36 Overcurrent Protection of Panelboards 451
 408.37 Panelboards in Damp or Wet Locations 452
 408.40 Equipment Grounding Conductor..... 452
 408.41 Neutral Conductor Terminations 453
Part IV. Construction Specifications..... 454
 408.54 Maximum Number of Overcurrent Devices..... 454

**ARTICLE 410—LUMINAIRES, LAMP HOLDERS, AND
 LAMPS**..... 455
Part I. General..... 455
 410.1 Scope 455
 410.2 Definitions 455
 410.6 Listing Required..... 456
Part II. Luminaire Locations..... 456
 410.10 Luminaires in Specific Locations..... 456
 410.11 Luminaires Near Combustible Material..... 458
 410.16 Luminaires in Clothes Closets 458
 410.18 Space for Cove Lighting..... 459
Part III. Luminaire Outlet Boxes and Covers 459
 410.22 Outlet Boxes to be Covered 459
 410.24 Connection of Electric-Discharge and LED Luminaires 459
Part IV. Luminaire Supports 460
 410.30 Supports..... 460

410.36 Means of Support	461	422.51 Cord-and-Plug-Connected Vending Machines.....	476
Part V. Grounding (Bonding)	462	422.52 Electric Drinking Fountains	476
410.44 Methods of Grounding.....	462	ARTICLE 424—FIXED ELECTRIC SPACE-HEATING	
Part VI. Wiring of Luminaires	463	EQUIPMENT	477
410.50 Polarization of Luminaires.....	463	Part I. General	477
410.62 Cord-Connected Luminaires	463	424.1 Scope	477
410.64 Luminaires as Raceways	464	424.3 Branch Circuits	477
410.68 Conductors and Ballasts	464	424.9 Permanently Installed Electric Baseboard Heaters with	
Part VIII. Installation of Lampholders	464	Receptacles.....	478
410.90 Screw-Shell Lampholders.....	464	Part III. Electric Space-Heating Equipment	478
410.96 Lampholders in Wet or Damp Locations	464	424.19 Disconnecting Means.....	478
410.97 Lampholders Near Combustible Material.....	464	Part V. Electric Space-Heating Cables	479
Part X. Recessed Luminaires	465	424.36 Clearances of Wiring in Ceilings	479
410.110 General.....	465	424.38 Area Restrictions.....	479
410.115 Thermally Protected	465	424.39 Clearance from Other Objects and Openings.....	479
410.116 Recessed Luminaire Clearances	465	424.44 Installation of Cables in Concrete or Poured	
410.117 Wiring.....	465	Masonry Floors.....	479
Part XII. Electric-Discharge Lighting	465	Part VI. Duct Heaters	479
410.130 General.....	465	424.65 Disconnect for Electric Duct Heater Controllers	479
Part XIV. Track Lighting	467	ARTICLE 430—MOTORS, MOTOR CIRCUITS, AND	
410.151 Installation.....	467	CONTROLLERS	480
410.154 Fastening.....	467	Part I. General	480
ARTICLE 411—LIGHTING SYSTEMS OPERATING AT		430.1 Scope	480
30V OR LESS	468	430.2 Definitions	480
411.1 Scope	468	430.6 Table FLC versus Motor Nameplate Current Rating.....	481
411.2 Definition	468	430.8 Marking on Controllers.....	482
411.3 Listing Required.....	468	430.9 Motor Controller Terminal Requirements	482
411.4 Specific Location Requirements.....	468	430.14 Location of Motors	483
411.5 Secondary Circuits.....	469	430.17 The Highest Rated Motor.....	483
ARTICLE 422—APPLIANCES	470	Part II. Conductor Size	483
Part I. General	470	430.22 Single Motor Conductor Size	483
422.1 Scope	470	430.24 Several Motors—Conductor Size	483
422.2 Definitions	470	430.28 Motor Feeder Taps	484
422.3 Other Articles	471	Part III. Overload Protection	484
Part II. Branch-Circuit Requirements	471	430.31 Overload	485
422.10 Branch-Circuit Rating	471	430.32 Overload Sizing for Continuous-Duty Motors	485
422.11 Overcurrent Protection.....	471	430.36 Use of Fuses for Overload Protection.....	486
422.12 Central Heating Equipment (Furnaces)	472	430.37 Number of Overload Devices.....	486
422.13 Storage Water Heaters	472	Part IV. Branch-Circuit Short-Circuit and Ground-Fault	
422.15 Central Vacuums.....	472	Protection	486
422.16 Flexible Cords.....	473	430.51 General.....	486
422.18 Support of Ceiling Paddle Fans.....	474	430.52 Branch-Circuit Short-Circuit and Ground-Fault	
Part III. Disconnect	474	Protection	487
422.30 General.....	474	430.55 Single Overcurrent Device.....	488
422.31 Permanently Connected Appliance Disconnects	474	Part V. Feeder Short-Circuit and Ground-Fault	
422.33 Cord-and-Plug-Connected Appliance Disconnects.....	475	Protection	489
422.34 Unit Switches as Disconnects	475	430.62 Feeder Protection.....	489

Part VI. Motor Control Circuits	490	ARTICLE 445—GENERATORS	500
430.72 Overcurrent Protection for Control Circuits	490	445.1 Scope	500
430.73 Protection of Conductors from Physical Damage	490	445.11 Marking	500
430.75 Disconnect for Control Circuits	490	445.12 Overcurrent Protection	500
Part VII. Motor Controllers	491	445.13 Ampacity of Conductors	500
430.83 Controller Rating	491	445.18 Disconnecting Means	502
430.84 Need Not Open All Conductors of the Circuit	491	445.19 Generators Supplying Multiple Loads	502
430.87 Controller for Each Motor	491	ARTICLE 450—TRANSFORMERS	503
Part IX. Disconnecting Means	491	Part I. General	503
430.102 Disconnect Requirement	491	450.1 Scope	503
430.103 Operation of Disconnect	493	450.3 Overcurrent Protection	503
430.104 Marking and Mounting	493	450.9 Ventilation	504
430.107 Readily Accessible	493	450.11 Marking	505
430.109 Disconnecting Means Rating	493	450.13 Transformer Accessibility	505
430.111 Combination Controller and Disconnect	493	450.14 Disconnecting Means	505
Part XIV. Tables	494	ARTICLE 480—STORAGE BATTERIES	506
Table 430.248 Full-Load Current, Single-Phase Motors	494	480.1 Scope	506
Table 430.250 Full-Load Current, Three-Phase Motors	494	480.2 Definitions	506
ARTICLE 440—AIR-CONDITIONING AND REFRIGERATION EQUIPMENT	495	480.3 Wiring and Equipment Supplied from Batteries	506
Part I. General	495	480.4 Overcurrent Protection for Prime Movers	507
440.1 Scope	495	480.5 Disconnecting Means	507
440.2 Definitions	495	480.8 Racks and Trays	507
440.3 Other Articles	495	480.9 Battery Locations	507
440.4 Marking on Hermetic Refrigerant Motor-Compressors and Equipment	495	Chapter 4. Equipment For General Use—Practice Questions	509
440.6 Ampacity and Rating	496	FINAL EXAM A	523
Part II. Disconnecting Means	496	FINAL EXAM B	532
440.12 Rating and Interrupting Capacity	496		
440.13 Cord-Connected Equipment	496		
440.14 Location	496		
Part III. Overcurrent Protection	497		
440.21 General	497		
440.22 Short-Circuit and Ground-Fault Overcurrent Device Size	497		
Part IV. Conductor Sizing	498		
440.32 Conductor Size for Single Motor-Compressors	498		
Part VII. Room Air Conditioners	498		
440.62 Branch-Circuit Requirements	498		
440.63 Disconnecting Means	498		
440.64 Supply Cords	499		
440.65 Leakage Current Detector-Interrupter and Arc-Fault Circuit Interrupter	499		